

DRAWINGS—Reference Numerals

1	Main scooper frame	7	Disposable bag
2	Frame right fork	8	Release cable
3	Frame left fork	9	Bag holder/release handle
4	Bag holder/release	10	Frame handle guide
5	Main scooper blade	11	Elastic part of bag
6	Disposable bag guide		




Fig.1: front view of the dispose a poop.




Fig. 2: side view of the dispose a poop. It also shows the disposable bag attached and the release handle to release the bag.






Fig. 3: top view of the scooper with the disposable bag attached.




Rear view




Top view

Fig.4: bag holder/release mechanism, both side view and top view.




Scoop up waste




Dispose waste

Fig. 5: demonstrates how one would scoop the dog waste and then hold it over a trashcan to release the disposable bag into the trashcan.



Hold disposable bag up to
release/holder arms



Releasing handle forces
arms to hold bag

Fig. 6